Base
Schlage

Schlage Base Application User Manual

SCHLAGE

Account Registration

Register

Singapore

Email Address

I Agree Privacy Policy and User Agreement

Get Verification Code

Log In

Sign Up

Try as Guest

For first time users, tap on the "Sign Up" button and select the country you are residing. Enter your email address. A verification code will then be sent via email.

Account Setup

Enter Verification Code

A verification code has been sent to your email evelyn.yling@gmail.com Resend (33s)

Didn't get a code?

Set Password

Password

Use 6-20 characters with a mix of letters and numbers

Done

Enter the verification code. In the next screen set up your password.

Add Device

Searching for nearby devices. Make sure your device has entered pairing mode.

Discovering devices...

Add

Add Manually

S8800   U8 Series Smart Lock   Lock (Wi-Fi)

Lock (BLE)   SEL3000   Smart Lock

No devices

Add Device

After logging into the app, select "Add Device". Device can also be auto-discovered or select "Lock (BLE)" and activate your Schlage lock according to the pairing instructions in the user manual (all user manuals can be found at schlage-locks.asia).

Unlock Device with Application

Add Device

1 device(s) being added

Rim Lock
Being added

Rim Lock

SCHLAGE

17:08 [Me] Set Volume [High]

Temporary Code

Member Management

Settings

After adding your Schlage lock, simply swipe right on the key icon to unlock your smart lock or swipe left to lock your device. You may unlock your device remotely (within bluetooth range) once added.

Audit Trail of Lock Activity

Rim Lock   **Log**

SCHLAGE

Time	Operate	User
22-08-2023 (Tue)		
17:30	[Me] Use [Password] Unlock with Code	
17:14	[Me] Remote Unlock	
17:08	[Me] Set Volume [High]	
17:08	[Me] Set Doorbell [step_8_max]	
17:08	[Me] Set Language [English]	
17:08	[Me] Set Language [Simplified Chinese]	
16:56	[eve] Remote Unlock	
16:41	[rym] Remote Unlock	
16:40	[rym] Remote Unlock	
16:39	[rym] Remote Unlock	

Temporary Code

Member Management

Settings

Tap on the bell icon to access a full audit trail of lock activity. The audit trail will only update when in Bluetooth range.

Generate Temporary Passcode

Rim Lock   **Temporary Unlock**   Records

SCHLAGE

17:08 Set Volume [High]

Temporary Code

Member Management

Settings

Code Type

Time-Limited   One-Time   Dynamic

Clearing   Custom

Please enter a 6-10 digit password

Enter   Random

Effective Time   22-08-2023 17:13

Expiration Time   Select

Code Name   Optional

Repeat Weekly

Save

Click "Temporary Code" for one-time, scheduled or custom codes to be sent to authorized users via email, SMS or other communication apps.
The lock does not need to be in Bluetooth range to activate/deactivate the code.

Member Management

Rim Lock   **Members**

SCHLAGE

17:08 [Me] Set Volume [High]

Temporary Code

Member Management

Settings

family member

Me Admin
evelyn.yling@gmail.com

John Doe
No associated accounts

share member

Tap on "Member Management" for full list of users. You can add new or remove user. Prior to adding new users, ensure that new users have already registered an account on the app. You can also set administrator access for each user.

Settings

Rim Lock   **Settings**

SCHLAGE

17:08 [Me] Set Volume [High]

Temporary Code

Member Management

Settings

Buzzer Volume   step_8_max

Voice Volume   High

Voice Language   English

Under "Settings", you can adjust Buzzer Volume, Voice Volume and Voice Language

---

Remove Device

Rim Lock

SCHLAGE

17:08 [Me] Set Volume [High]

Temporary Code

Member Management

Settings

Rim Lock

Device Information

Others

Create Group

FAQ & Feedback

Add to Home Screen

Device Update   No updates available

Remove Device

Tap on the edit icon and select "Remove Device" to completely delete the device and its information from your app.

ALLEGION